

Resistance Thermometers DiwiTherm®, with Digital Display Model DR, Battery Powered/Output 4 ... 20 mA

WIKA Data Sheet TE 50.01



Applications

- Machinery, plant and tank construction
- Chemical industry
- Food and beverage industry
- Automotive industry
- Sanitary, heating and air-conditioning technology

Special Features

- LCD display, 18 mm high figures
- Battery powered or output 4 ... 20 mA
- Versions with insertion sensor, for additional thermowell or with contact bulb for tube skin mounting
- Suitable for all standard thermowell designs
- Intrinsically safe versions (ATEX)



Fig. left: DiwiTherm® Model DR210 Fig. centre: DiwiTherm® Model DR111 Fig. right: DiwiTherm® Model DR610

Description

The DiwiTherm® is an ideal combination of a digital indicator and a resistance thermometer. This compact temperature measuring instrument can be used for a variety of applications and works without external power supply. The large-scale LCD display is very clear and easy to read.

An extensive range of insertion lengths, neck lengths, thermowell connections etc. are available for these thermometers, so that they are suitable for all thermowell dimensions and applications.

Operation without thermowell is only recommended for specific applications.

The DiwiTherm® can be manufactured with an optional process connection for tube skin temperature measurement. An analogue 4 ... 20 mA output is also available as an option.

Intrinsically safe designs are available for applications in hazardous areas. The battery powered models are provided with a type-examination certificate for "intrinsically safe" type of protection according to directive 94/9/EC (ATEX).

Models	DiwiTherm®
DR1XX	Insertion sensor
DR 2 XX	Probe for additional thermowell
DR 6 XX	Contact bulb for tube skin mounting
DRX1X	Battery powered
DRX 2 X	Output 4 20 mA
DRX 3 X	Solar operation (see data sheet TE 50.02)
DRXX 0	radial / adjustable every angle (with extension neck)
DRXX1	axial (with connection cable)

WIKA Data Sheet TE 50.01 · 04/2006

Page 1 of 12





Specifications	DiwiTherm [®]
Measuring range	
Display in °C	- 50 + 199.9 °C or - 50 + 400 °C
Display in °F	- 50 + 750 °F
Display	
Principle	3½ - digit, LCD, 18 mm high figures
Resolution	0,1 °C with measuring range - 50 °C + 199.9 °C
	1 °C with measuring range - 50 °C + 400 °C
	1 °F with measuring range - 50 °F + 750 °F
Measuring deviation 1) DIN IEC 770, 23 °C ± 5 K	± (0.5 K + 0.5 % of measured value in °C + 1 Digit)
Temperature coefficient	± 0.02 % of measuring span / K _{Tamb} ²⁾
DiwiTherm® with insertion sensor	
Design	Sensor with connection cable
	Case for panel mounting, with panel mounting flange
DiwiTherm® for additional thermowell	
Design	Probe spring-loaded
	Male thread to thermowell
	Case with extension neck
Option	■ Case adjustable every angle, axial (rotatable on extension neck 360°)
DiwiTherm® for tube skin mounting	
Design	Contact bulb for mounting by means of a strap retainer
	Case with extension neck
Option	Case adjustable every angle, axial (rotatable on extension neck 360°)
	Case for panel mounting, with connection cable and panel mounting flange
Case	400
Nominal size	100
Material	Stainless steel
Ingress protection	IP 65 (EN 60529 / IEC 529)
Bezel ring	Cam ring (bayonet type)
Window	Instrument glass
Electromagnetic compatibility (EMC)	
CE - Conformity per	DIN EN 61326-1 (1998-01)
Special features	
Sensor	Pt1000
Ambient and storage temperature	Battery powered design: - 10 + 60 °C, with output 4 20 mA: - 10 + 70 °C
Vibration	10 500 Hz 5 g IEC 68 2-6
Shock	DIN IEC 68 2-27
Weight	Approx. 1 kg

DiwiTherm® Battery powered	
Power supply U _B	DC 3.6 V by battery ³⁾
Operating duration	at least 3 years
Ex-protection	Type-examination certificate for "intrinsically safe" ignition protection (EEx i) per directive 94/9/EG (ATEX)
Permissible ambient temperature	See operating instructions
Maximum values for connection	See operating instructions

DiwiTherm [®] with output 4 20 mA	
Analogue output	4 20 mA 2 wire design
Load R _A	$R_A \le (U_B - 10 \text{ V}) / 0.02 \text{ A}$ with R_A in Ω and U_B^{4} in V
Load effect	\pm 0,05 % of measuring span / 100 Ω
Measuring deviation per DIN IEC 770, 23 °C ± 5 K	± (0.5 K + 0.5 % of measured value)
Temperature coefficient	± 0.02 % of measuring span / K _{TU} ²⁾
Power supply effect	± 0.025 % of measuring span / V
Behaviour of sensor burnout	Up scale, ≥ 21 mA
Behaviour of sensor short circuit	Down scale, ≤ 3.6 mA
Power supply U _B	DC 10 30 V by 4 20 mA-loop
Max. permissible ripple	10 %
Electrical connection	Terminal box (screw terminals up to 2.5 mm²)
Input power supply protection	Reverse polarity, overvoltage, and short circuiting

In defined measuring range
 Tamb = ambient temperature (other than 20 °C)
 Lithium battery with 3.6 V size AA (Mignon) is included in the standard of delivery
 U_B = loop power supply voltage, see power supply



DiwiTherm® with insertion sensor Model DR1X1

Sensor

Material: stainless steel 1.4571

Sensor length $I_1 \le 150$ mm: rigid sensor tube

Sensor length from 150 mm: measuring cable (MI cable)
The diameter of the sensor shall be approx. 1 mm smaller than the hole diameter of the thermowell or the blind hole.
Gaps of more than 0.5 mm between thermowell and sensor will have a negative effect on the heat transfer, and they will result in an unfavourable response behaviour of the thermometer.

Sensor lengths

Sensor Ø in mm	Standar	d sensor	lengths I ₁ in mm	
6	50	100	150	
8	-	100	150	

Special lengths are possible

Process connection

A compression fitting enables easy adaptation to the desired insertion length at the mounting location.

Compression fitting


Material: stainless steel 1.4571


Male thread G % B (not with probe Ø 8 mm) or G % B Delivery also possible without process connection

Cable

PVC, application range -20 °C ... +100 °C Silicone, application range -50 °C ... +200 °C PTFE, application range -50 °C ... +250 °C Sheathed cable, d = 6 mm

Cable length to customer specification
Maximum cable length for versions intended for use in
hazardous areas: 3000 mm








DiwiTherm® for additional thermowell Model DR2X0

Connection to thermowell



Probe

Material: stainless steel 1.4571

The probe is made of a vibration-resistant sheathed measuring cable (MI cable).

The diameter of the probe should be approx. 1 mm less than the diameter of the thermowell hole in which the probe is to be fitted.

The diameter of the probe shall be approx. 1 mm smaller than the hole diameter of the thermowell.

Gaps of more than 0.5 mm between thermowell and probe will have a negative effect on the heat transfer, and they will result in an unfavourable response behaviour of the thermometer.

When fitting the measuring insert with a thermowell, it is very important to determine the correct insertion length (= thermowell length with bottom thicknesses of ≤ 5.5 mm). In this connection the fact that the measuring insert is spring-loaded (spring travel: max. 10 mm) has to be taken into account in order to ensure that the probe presses against the bottom of the thermowell.

Insertion lengths

Probe Ø in mm	Stan	Standard insertion lengths I ₁ in mm															
3	110	140	145	170	200	205	230	245	260	295	305	345	350	395	410	445	545
6	-	-	-	170	200	205	230	245	260	295	305	345	350	395	410	445	545
8	-	-	-	-	200	205	230	245	260	295	305	345	350	395	410	445	545

Special lengths are possible.

Process connection (Standard process connection)

Material: stainless steel 1.4571

M14 x 1.5 M18 x 1.5 ½ NPT

Union nut: G ½ B Swivel nut: G ½ B

Male thread: G ½ B

Extension neck


Material: stainless steel 1.4571 Extension neck diameter: 11 mm Standard neck length: 150 mm


other on inquiry

(minimum neck length: 30 mm)



Dimensions in mm





Inspection plug (at 9 o'clock) with battery powered design only, terminal box (at 3 o'clock) with output 4 \dots 20 mA design only



DiwiTherm® for tube skin mounting Model DR6X0

DiwiTherm® Model DR6X0 for tube skin mounting, with extension neck Connection from case to extension neck: fixed, radial bottom

Tube skin mounted contact bulb

Material: stainless steel 1.4571 Fastening tube: 120 mm


Fastening by means of strap retainer (not included in the scope of delivery)

Extension neck

Material: stainless steel 1.4571 Extension neck diameter: 11 mm Standard neck length: 150 mm

other on inquiry

(minimum neck length: 100 mm)



Inspection plug (at 9 o'clock) with battery powered design only, terminal box (at 3 o'clock) with output 4 ... 20 mA design only



DiwiTherm® for tube skin mounting Model DR6X1

Tube skin mounted contact bulb

Material: stainless steel 1.4571 Fastening tube: 120 mm

Fastening by means of strap retainer (not included in the

scope of delivery)

Cable


PVC, application range -20 °C ... +100 °C Silicone, application range -50 °C ... +200 °C PTFE, application range -50 °C ... +250 °C

Sheathed cable, d = 6 mm

Cable length to customer specification

Maximum cable length for versions intended for use in


hazardous areas: 3000 mm



Mounting instructions for contact bulb

General


The contact bulb has been designed for mounting on a tube or tank skin. The contact bulb is to be mounted so that it lays over the measuring point down its full length. Basic requirements to ensure perfect measurement results are good thermal contact between the skin mounted contact bulb and the outside wall of the tube or tank with minimal heat loss to the ambient from the skin mounted contact bulb and measuring point.



Mounting on tubes

The geometry of the contact bulb has been designed for tubes with external diameters between 20 and 160 mm. Tube clips are adequate for fastening the skin mounted contact bulb to the tube. The skin mounted contact bulb should have direct metallic contact with the measuring point and have firm contact with the surface of the tube.

In so far as temperatures under 200 °C are to be expected a heat conductive paste can be used to optimise the heat transmission between skin mounted contact bulb and tube. Lagging must be applied where the skin mounted contact bulb has been mounted to avoid error due to heat loss. This lagging must have sufficient temperature resistance and is not provided with the instrument.




Mounting on tanks

The geometry of the contact bulb has been designed for tanks with an external radius up to 80 mm. If the mounting point of the skin mounting contact bulb on the tank has an external radius greater than 80 mm, we recommend the use of an intermediate piece designed for the respective tank diameter made of a material with good thermal conductivity. The contact bulb should be fastened to the



tank by means of an angle bracket with clamping screws, or any similar method.


The skin mounted contact bulb should have direct metallic contact with the measuring point and have firm contact with the surface of the tank. In so far as temperatures under 200 °C are to be expected a heat conductive paste can be used to optimise the heat transmission between skin mounted contact bulb and tank. Lagging must be applied where the skin mounted contact bulb has been mounted to avoid error due to heat loss. This lagging must have sufficient temperature resistance and is not provided with the instrument.




Connector plugs

DiwiTherm® with output 4 ... 20 mA: L-plug per DIN EN 17 5301-803 (DIN 43 650), Silicone seal between fixed and free connector

Electrical connection



Changing of battery



Explosion protection (option)

Battery powered DiwiTherm® are available with a type examination certificate for "intrinsically safe" ignition protection (II 2G EEx ia IIC T4, DMT 98 ATEX E 018). These thermometers comply with the requirements of directive 94/9/EC (ATEX).

Maximum cable length for versions intended for use in hazardous areas: 3000 mm


The responsibility for using suitable thermowells rests with the user.



Ordering information for DiwiTherm® Model DR111 and DR121

Field N	lo.	Code	Feature	res	
			Model		
		DR111		1, DiwiTherm® with insertion sensor, battery powered, with connection cable (axial)	
1				1, DiwiTherm® with insertion sensor, with output 4 20 mA, with connection cable (axial)	
		•			
			Explosi	sion protection	
		Z	without		
2		9		EEx ia IIC T4 only model DR111 and only if cable shorter than	1 3000 mm
				uring range	
		EL		+199.9 °C +400 °C	
2		EQ ER		+750 °F	
3		EK		ss connection	
		ZZ	without		
		K1		B, compression fitting, stainless steel	
		K2		B, compression fitting, stainless steel	
4		??	other	please state as add	ditional text
		-	Sensor	or diameter	
		3	6 mm		
		4	8 mm		
5		?	other	please state as add	ditional text
			Sensor	or length	
		1	50 mm		
		2	100 mm		
		3	150 mm		
6		?	other	please state as ad	ditional text
				or material	
7		?	other	ss steel 1.4571 please state as add	ditional taxt
,		ſ	Cable	piease state as au	uitioriai text
		Р		application range -20 °C +100 °C	
		s		e, application range -50 °C +200 °C	
		T		application range -50 °C +250 °C	
		М		ned cable (MI cable), d = 6 mm	
8		?	other	please state as add	ditional text
		•	Cable le	length	
			length in	in mm, e.g. 0850 for 850 mm with explosion protection max. lengt	th 3000 mm
9		????	longer th	than 9999 mm please state as add	ditional text
	·	Addition	nal order	or info	
		YES	No	ar milo	
10		1	Z	quality certificates si	ee price list
11	+	 '	Z	additional text Please state as clearly understar	
	<u> </u>			additional text Flease state as Clearly understan	ועמטוכ וכאנ!

Order code:





Ordering information for DiwiTherm® Model DR210 and DR220


Model DR210 DR210, DiwiTherm® for additional thermowell, battery powered DR220 DR220, DiwiTherm® for additional thermowell, with output 4 20 mA Explosion protection Z without 9 II 2G EEx ia IIC T4	only model DR210
DR210 DR210, DiwiTherm® for additional thermowell, battery powered DR220 DR220, DiwiTherm® for additional thermowell, with output 4 20 mA Explosion protection Z without	only model DR210
DR220 DR220, DiwiTherm® for additional thermowell, with output 4 20 mA Explosion protection Z without	only model DR210
Explosion protection Z without	only model DR210
Z without	only model DR210
Z without	only model DR210
	only model DR210
	Only model bix210
Measuring range	
EL -50 °C +199.9 °C	
EQ -50 °C +400 °C	
3 ER -50 °F +750 °F	
Connection from case to extension neck	
R fixed, radial	
S adjustable every angle, axial	
Probe diameter	
1 3 mm	
3 6 mm	
4 8 mm	tubing
5 ? other	please state as additional text
Insertion length	
0110 110 mm	
0140 140 mm	
0145 145 mm	
0170 170 mm	
0200 200 mm	
0205 205 mm	
0230 230 mm	
0245 245 mm	
0260 260 mm	
0295 295 mm	
0305 305 mm	
0345 345 mm	
0350 350 mm	
0395 395 mm 0410 410 mm	
0445 445 mm	
0545 545 mm	
6 length in mm, e.g. 0850 for 850 mm	
Neck length	
5 150 mm	
7 ? other	please state as additional text
Connection to thermowell / extension neck diameter	
A1 male thread G 1/2 B / diameter 11 mm	
B1 male thread M14 x 1,5 / diameter 11 mm	
C1 male thread M18 x 1,5 / diameter 11 mm	
I1 union nut M24 x 1,5 / diameter 11 mm	
E1 union nut M27 x 2 / diameter 11 mm	
F1 union nut G 1/2 / diameter 11 mm	
G1 swivel nut G 1/2 B / diameter 11 mm	
8 7 other	please state as additional text
Additional order info	
YES No	
9 1 Z quality certificates	see price list
10 T Z additional text	Please state as clearly understandable text!
YES No 1 Z quality certificates	
Additional text:	



Ordering information for DiwiTherm® Model DR611 and DR621

Field N	lo.	Code	Feature	es
			Model	
		DR611	DR611,	DiwiTherm® for tube skin mounting, battery powered, with connection cable (axial)
1		DR621	DR621,	DiwiTherm® for tube skin mounting, with output 4 20 mA, with connection cable (axial)
				on protection
		Z	without	
2		9	II 2G EE	Ex ia IIC T4 only model DR611 and only if cable shorter than 3000 mm
			Measur	ing range
		EL	-50 °C	+199.9 °C
		EQ	-50 °C	+400 °C
3		ER	-50 °F .	+750 °F
			Cable	
		Р	PVC, ap	oplication range -20 °C +100 °C
		S	Silicone	, application range -50 °C +200 °C
		Т	PTFE, a	application range -50 °C +250 °C
		M	sheathe	ed cable (MI cable), d = 6 mm
4		?	other	please state as additional text
			Cable le	ength
			length in	n mm, e.g. 0850 for 850 mm with explosion protection max. length 3000 mm
5		????	longer th	han 9999 mm please state as additional text
		Addition	nal order	r info
		YES	No	
6		1	Z	quality certificates see price list
7		Т	Z	additional text Please state as clearly understandable text!

Order code:





Ordering information for DiwiTherm® Model DR610 and DR620

Field N	0.	Code	Feature	5
			Model	
		DR610	DR610,	DiwiTherm® for tube skin mounting, battery powered
1		DR620	DR620,	DiwiTherm® for tube skin mounting, with output 4 20 mA
				on protection
		Z	without	
2		9	II 2G EE	x ia IIC T4 only model DR610
			Measuri	ng range
		EL	-50 °C	. +199.9 °C
		EQ	-50 °C	. +400 °C
3		ER	-50 °F	. +750 °F
·-			Connec	tion from case to extension neck
		R	fixed, ra	dial
4		S	adjustab	le every angle, axial
·-			Neck le	ngth
		5	150 mm	
5		?	other	please state as additional text
		Additio	nal order	info
		YES	No	
6		1	Z	quality certificates see price list
7		Т	Z	additional text Please state as clearly understandable text!

Order code:

Page 12 of 12

	1	2	3	4 5	(5 7			
		□- □-Г					1		
Additi	ional text:								
	_								

Specifications and dimensions given in this leaflet represent the state of engineering at the time of printing. Modifications may take place and materials specified may be replaced by others without prior notice.



WIKA Alexander Wiegand GmbH & Co. KG

WIKA Data Sheet TE 50.01 · 04/2006

Alexander-Wiegand-Straße 30 63911 Klingenberg/Germany Phone (+49) 93 72/132-0 (+49) 93 72/132-406 Fax

E-Mail info@wika.de

www.wika.de